

Ural Maintenance



Dyna Beads For Tire Balancing

P/N 960104 M

Balance your wheels without the necessity of using a spin or drop balancer. Ceramic beads inserted thru valve stem hole find correct balance point each time the tire begins to rotate. Not affected by moisture. Will not damage tube interior. Lasts the life of the tube (or if you are tubeless - the life of the tire. Balancing action is totally automatic. If you change a worn out tire and use already loaded tube - no re balancing is necessary. No wheel weights to add or fly off. Requires patience to install is the only downside. Results well worth the effort. Requires 2 -3 oz per tire.

Why Put Up With A Lumpy Ride - Go Dyna Ride !

Raceway Services

2700 19th St. SE Unit #3
Salem, OREGON 97302

503-588-7227

racewayservices@gmail.com

503-871-0197 cell
503-363-6952 fax

\$2.95 oz